

ELK Project


Last Class Some of You Only Gained SSH Access



A Few of You Set Up Ansible




And Three of Us Connected Ansible to the Web Servers




Day 1 Start


Original Project




New Project



- 1. Forget About Ansible
- 2. Delete Any Containers on Web1
 - 3. Delete VM Web 2
- 4. Create Usernames and Passwords for both VMs Certs will not be used



Setup DVWA



- 1. SSH into the Jump Server and use it to SSH into the Web1
- 2. Run the DVWA Script that Terrace and Steve Created and Thank Them


```
mv Filebeat /etc/filebeat/filebeat.yml
#!/bin/bash
if ! [ (id -u) = 0 ]; then
   echo "The script need to be run as root." >&2
   exit 1
fi
if [ $SUDO_USER ]; then
    real_user=$SUDO_USER
else
    real_user=$(whoami)
#Check to see if user is Root
echo apt update && apt upgrade
#Update and upgrade Current VM
apt install docker.io
#installs docker to box
apt install python3-pip
#installs python
apt install docker
#installs docker python module
systemctl start docker
#starts docker
docker pull vulnerables/web-dvwa
#pulls docker Dvwa
docker run --rm -it -p 80:80 vulnerables/web-dvwa
#Create Image
```

If It's Working.....

```
root@Jump-Box: /home/jack
  ok | Starting MariaDB database server: mysgld.
 +] Starting apache
  ...] Starting Apache httpd web server: apache2AH00558: apache2: Could not reliably determine the server
 s fully qualified domain name, using 172.17.0.2. Set the 'ServerName' directive globally to suppress th
 => /var/log/apache2/access.log <==
 => /var/log/apache2/error.log <==
[Sat Oct 10 04:04:21.645794 2020] [mpm_prefork:notice] [pid 302] AH00163: Apache/2.4.25 (Debian) configur
ed -- resuming normal operations
[Sat Oct 10 04:04:21.645880 2020] [core:notice] [pid 302] AH00094: Command line: '/usr/sbin/apache2'
==> /var/log/apache2/other_vhosts_access.log <==
 => /var/log/apache2/access.log <==</pre>
99.2.0.163 - - [10/oct/2020:04:05:11 +0000] "GET / HTTP/1.1" 302 479 "-" "Mozilla/5.0 (windows NT 10.0;
in64; x64) ApplewebKit/537.36 (KHTML, like Gecko) Chrome/86.0.4240.75 Safari/537.36 Edg/86.0.622.38"
99.2.0.163 - - [10/oct/2020:04:05:11 +0000] "GET /login.php HTTP/1.1" 200 1049 "-" "Mozilla/5.0 (Windows
NT 10.0; Win64; x64) AppleWebKit/537.36 (KHTML, like Gecko) Chrome/86.0.4240.75 Safari/537.36 Edg/86.0.62
99.2.0.163 - - [10/oct/2020:04:05:11 +0000] "GET /dvwa/css/login.css HTTP/1.1" 200 741 "http://13.67.214
91/login.php" "Mozilla/5.0 (Windows NT 10.0; Win64; x64) ApplewebKit/537.36 (KHTML, like Gecko) Chrome/86
.0.4240.75 Safari/537.36 Edg/86.0.622.38"
99.2.0.163 - - [10/oct/2020:04:05:11 +0000] "GET /dvwa/images/login_logo.png HTTP/1.1" 200 9375 "http://
3.67.214.91/login.php" "Mozilla/5.0 (Windows NT 10.0; Win64; x64) ApplewebKit/537.36 (KHTML, like Gecko)
Chrome/86.0.4240.75 Safari/537.36 Edg/86.0.622.38"
99.2.0.163 - - [10/oct/2020:04:05:11 +0000] "GET /favicon.ico HTTP/1.1" 200 1706 "http://13.67.214.91/loc
in.php" "Mozilla/5.0 (Windows NT 10.0; Win64; x64) AppleWebKit/537.36 (KHTML, like Gecko) Chrome/86.0.424
 .75 Safari/537.36 Edg/86.0.622.38"
```


- 1. Create a Load Balancer and add Web01 into it
- 2. Open port 80 from your Load Balancer to your Web server (NSG)

https://www.youtube.com/watch?v=-VMPzVoo5Nk




- 1. Test Connecting to the DVWA Using the Public IP of the Load Balancer
- 2. Log in following the below Instructions Start reading where the images start, ignore everything before it

https://hub.docker.com/r/vulnerables/web-dvwa



Just click on the Create / Reset database button and it will generate any aditional configuration needed.

- 1. Create New Resource Group "Management"
- 2. Create New Subnet in Existing Virtual Network
- 3. Create New NSG "Management" in Management Resource Group
 - 4. Associate NSG to "Management" Subnet
 - 5. Move Existing VNET to New Resource Group




1. Create a Simple New VM, in Resource Group "Management", Called "ELK".

Create a username and password and make sure the B series VM has 2 CPUs and 4gb of Memory

Make Sure you Don't Create a NEW NSG as part of the Setup

Give it a Public IP

2. Verify you can SSH into it the new VM




Install ELK

```
#!/bin/bash
if![$(id -u) = 0]; then
 echo "The script need to be run as root." >&2
 exit 1
fi
if [ $SUDO_USER ]; then
 real_user=$SUDO_USER
else
 real_user=$(whoami)
#Check to see if user is Root
echo apt update && apt upgrade
#Update and upgrade Current VM
apt install docker.io
#installs docker to box
apt install python3-pip
#installs python
apt install docker
#installs docker python module
sysctl -w vm.max_map_count=262144
#increases virtual memory
systemctl start docker
#starts docker
docker pull sebp/elk
#pulls docker elk
docker run -p 5601:5601 -p 9200:9200 -p 5044:5044 -it sebp/elk
#Create Image
```

Connect to ELK and Login


- 1. Modify the "management" NSG to Allow your Home IP to connect to the Elk Internal IP on port 5601
 - 2. Browse to http://Your_IP:5601/app/kibana and Login to change the default password




Day 1 Complete


Day 2 Start

Where We Left Off




Goal Push Logs from Web01 to ELK





By the End of Today You Should Have



Install File Beat on Web Server

1. SSH into the Web Server through the Jumpbox

```
#download filebeat curl -L -O https://ln2.sync.com/dl/18aa05e60/zkc82r7a-adqnqwrk-9in3s62h-3yyj7kug #rename file mv zkc82r7a-adqnqwrk-9in3s62h-3yyj7kug filebeat-6.8.12-amd64.deb #install filebeat sudo dpkg -i filebeat-6.8.12-amd64.deb
```

ref: https://www.elastic.co/guide/en/beats/filebeat/6.8/filebeat-installation.html

Download the Config File, Move it, and Add Dest Server


```
#download
curl -O -L https://gist.githubusercontent.com/slape/5cc350109583af6cbe577bbcc0710c93/raw/eca603b72586fbe148c11f9c87bf96a63cb25760/Filebeat
#move
mv Filebeat /etc/filebeat/filebeat.yml
#open
Nano /etc/filebeat/filebeat.yml
#update Config to Point to ELK Server
Scroll to line #1106 and replace the IP address with the IP address of your ELK machine. And Update Password.
output.elasticsearch:
hosts: ["10.1.0.4:9200"]
username: "elastic"
password: "changeme"
Scroll to line #1806 and replace the IP address with the IP address of your ELK machine.
setup.kibana:
host: "10.1.0.4:5601"
```

Open Port On Management NSG and Start Service

1. In Azure, navigate to the Management NSG and Open the needed port from Web Server to ELK = 9200
2. After, Start the Filebeat on the Web Server

filebeat modules enable system
filebeat setup
service filebeat start

Final Elk Project



Day 2 End

Day 3 Start

Home Work

 Create a Github Repository https://www.youtube.com/watch?v=XtCcoMd6U_4

- Create and Add a Network Diagram
- The Firewall Spreadsheet with access rules
- The "why"

Day 3 End